



## A typical installation of a Mk2 PV Router.

The CT needs to be clipped around one of the 'live' incoming feeds, i.e Neutral or Line. When the rate of energy generation exceeds consumption, surplus power will be diverted to the load in such a way that the net flow of current at the supply point is zero.